



Read this manual before operation

# Installation & Operation Manual

## Crepe Maker

### TEG-1/2



Dear Customer & User,

Thank you for purchasing our appliance. Before use and operation, please read and familiarize yourself with the following operating and safety instructions. **SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.** Save the original box and packaging. Use this packaging to ship the equipment if repairs are needed.

This manual contains important information, please read the manual thoroughly prior to equipment set-up, operation and maintenance. Failure to comply with regular maintenance guidelines outlined in this manual may void the warranty.

The user's manual should be always available for operation. So make sure this manual book is properly placed. We have the full authority to reserve the further technical changes of the device, in the scope of further performance improvement characteristic development.

# WARNINGS


- Do not store or use gasoline or other flammable vapors or liquids in the vicinity of this or any other equipment.
- Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death.
- Read the installation and maintenance instructions thoroughly before installing or servicing this equipment.
- Have the equipment installed by a qualified installer in accordance with all federal, state and local codes.
- Do not install or use without all 4 legs.
- This equipment is for use in non-combustible locations only.
- Do not obstruct the flow of combustion and ventilation air.
- Do not spray controls or the outside of the equipment with liquids or cleaning agents
- Allow for hot parts to cool before cleaning or moving.
- This equipment should only be used in a flat, level position.
- Do not operate unattended.
- When using, hand, plug and switch must be dry.

## Product parameters table

Model	Dimensions(inch)	Power(KW)	Volts.	N.W(KG)
TEG-1	17.72×19.09×9.45	3	220V/60HZ/1PH	23
TEG-2	33.86×19.09×9.45	6	220V/60HZ/1PH	42

## Circuit Diagram


TEG-1



QS Temperature limiter    EH Heating Element    ST Thermostat

HL1 Power indicator    HL2 Heating indicator

## TEG-2



QS1 QS2 Temperature limiter    EH1 EH2 Heating Element

ST1 ST2    Thermostat

HL1 HL2 Power indicator    HL3 HL4 Heating indicator

## INSTALLATIONS

1. Remove all packing material and tape, as well as any protective plastic from the equipment.
2. Place the equipment in the desired position and height.
3. Clean and dry the equipment thoroughly before using.

## **Safety Instructions:**

- The device is not intended for use by individuals (including children) with physical or mental disabilities, insufficient experience, and/or insufficient knowledge unless such persons are under the care of a person responsible for their safety or have received instructions regarding appropriate use of the device.
- Children should be observed to ensure that they are not playing with the device.
- Do not leave the device unattended during operation since there might occur malfunctions which could result in overheating of the oil. In case of high temperatures oil might ignite.
- Never leave the device unattended when in use.
- The device is not adapted for use with an external timer or remote control.
- This device may only be operated in technically proper and safe condition.
- Prevent access of children to the package materials like plastic bags and foamed polystyrene elements. Suffocation hazard!
- Only a qualified technician and using original spare parts and accessories should carry out repairs and maintenance of the device. Do not attempt to repair the device yourself.
- Do not use any accessory or spare parts that have not been recommended by the manufacturer. These can be dangerous for the user or lead to damages of the device or personal injury, and further, the warranty expires.
- To prevent hazards and to ensure optimum efficiency, no modifications or alterations to the device that are not explicitly approved by the manufacturer may be undertaken.

## Care and Cleaning:

1. Unplug the power cable and ensure that the product is cooled completely, then cleaning and collection.
2. Cleaning cooking surface with a soft cloth or sponge dampened in a mild detergent.
3. Please don't use wire brush, stiff brush or other corrosive liquids to clean it, avoiding damage the surface coating.
4. Never clean the product by sprinkling water and immersed in water.

## Failure Analysis & Trouble Shooting:

Symptoms	Causes	Solutions
The heating control light comes on, the temperature does not increase.	1.The Thermostat is malfunctioning	1.Replace the thermostat
	2.The Heating element is malfunctioning	2、 Replace the Heating element.
When the power is on and temperature controller is switched and heating indicator is on but the temperature can not be controlled.	The Thermostat is malfunctioning	Replace the thermostat
When the heating elements are working, the heating indicator (yellow) is not on.	The indicator is malfunctioning.	Replace the indicator.
The indicator is not on ,and the temperature does not increase.	1. Abnormal power supply or cut-off power supply.	1. Check power supply and connection to make power supply be normal.
	2. Fuse is burned.	2. Change fuse.